

# HEALTHCARE CLEANING PROTOCOL FOR LOBBIES, AREAS SUBJECT TO HEAVY TRAFFIC AND WALKING ZONES



## Damp sweeping equipment

Flexible mop preferably fitted with disposable, antistatic and/or pre-impregnated gauze strips














## Mechanical cleaning equipment

Auto scrubber, rotocleaner or single brush machine



## Manual washing equipment

Microfibre disposable mop or gauze

	Minimum frequency	Equipment used	Cleaning products	Cleaning methods
First use		  	Alkaline detergent	<ul style="list-style-type: none"> <li>• Damp sweeping</li> <li>• Mechanical washing with blue disk at 300-450 rpm (with water recovery)</li> </ul>
Daily care	Once or twice daily	   or  almond	Neutral detergent	<ul style="list-style-type: none"> <li>• Damp sweeping</li> <li>• Mechanical washing at 300-450 rpm (with water recovery)</li> </ul>
Deep cleaning	Once a month	   or  almond	Alkaline detergent	<ul style="list-style-type: none"> <li>• Damp sweeping</li> <li>• Mechanical washing at 300-450 rpm (with water recovery)</li> </ul>

To offer you the best results in terms of hygiene and appearance, **Gerflor recommends that you use neutral and alkaline detergents with high wetting power** (perfect spreading and cleaning of the entire floor surface).

### Here is a non-exhaustive list of products recommended by the main manufacturers:

**KIEHL:** Profloor\*  
**TANA:** Green care SR15\*,  
 Floor Cleaner S\*, Clean Fresh\*,  
 Difotan\*, Clean Extreme\*\*,  
 Innomat\*\*

\*Neutral / \*\*Alkaline

**ECOLAB:** Brial Clean S\*  
**ROCHEX:** Polystar\*, Roctonic\*\*  
**BUZIL:** HC 43\*\*  
**DrSCHUTZ:** PU Reiniger\*

**DREITURM:** Multinetzer\*,  
 Goldreif (green)\*, Goldreif  
 (blue)\*, Linorein\*\*, D1 Neu\*\*

### CLEANING METHOD FOR:

Mipolam Troplan / Cosmo / Elegance / Accord / Esprit / Symbioz

# HEALTHCARE CLEANING PROTOCOL FOR PASSAGEWAYS



## Damp sweeping equipment

Flexible mop preferably fitted with disposable, antistatic and/or pre-impregnated gauze strips
















## Mechanical cleaning equipment

Auto scrubber, rotocleaner or single brush machine



## Manual washing equipment

Microfibre disposable mop or gauze

	Minimum frequency	Equipment used	Cleaning products	Cleaning methods
First use		  	Alkaline detergent	<ul style="list-style-type: none"> <li>• Damp sweeping</li> <li>• Mechanical washing with blue disk at 300-450 rpm (with water recovery)</li> </ul>
Daily care	Once daily	   or  almond or 	Neutral detergent	<ul style="list-style-type: none"> <li>• Damp sweeping</li> <li>• Mechanical washing at 300-450 rpm (with water recovery)</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>• Steam cleaning</li> </ul>
Deep cleaning	Once a month	   or  almond or 	Alkaline detergent	<ul style="list-style-type: none"> <li>• Damp sweeping</li> <li>• Mechanical washing at 300-450 rpm (with water recovery)</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>• Steam cleaning</li> </ul>

To offer you the best results in terms of hygiene and appearance, **Gerflor recommends that you use neutral and alkaline detergents with high wetting power** (perfect spreading and cleaning of the entire floor surface).

### Here is a non-exhaustive list of products recommended by the main manufacturers:

**KIEHL:** Profloor\*  
**TANA:** Green care SR15\*,  
 Floor Cleaner S\*, Clean Fresh\*,  
 Difotan\*, Clean Extreme\*\*,  
 Innomat\*\*

\*Neutral / \*\*Alkaline

**ECOLAB:** Brial Clean S\*  
**ROCHEX:** Polystar\*, Roctonic\*\*  
**BUZIL:** HC 43\*\*  
**DrSCHUTZ:** PU Reiniger\*

**DREITURM:** Multinetzer\*,  
 Goldreif (green)\*, Goldreif  
 (blue)\*, Linorein\*\*, D1 Neu\*\*

### CLEANING METHOD FOR:

Mipolam Troplan / Cosmo / Elegance / Accord / Esprit / Symbioz

# HEALTHCARE CLEANING PROTOCOL FOR BEDROOMS



## Damp sweeping equipment

Flexible mop preferably fitted with disposable, antistatic and/or pre-impregnated gauze strips



## Mechanical cleaning equipment

Auto scrubber, rotocleaner or single brush machine

















## Manual washing equipment

Microfibre disposable mop or gauze



## Steam cleaning equipment

Follow the manufacturer's recommendations

	Minimum frequency	Equipment used	Cleaning products	Cleaning methods
<b>First use</b>				
<b>Mechanical cleaning</b>		  	Alkaline detergent	<ul style="list-style-type: none"> <li>• Damp sweeping</li> <li>• Mechanical washing with blue disk at 300-450 rpm (with water recovery)</li> </ul>
<b>Daily care</b>				
<b>Manual cleaning</b>	Once daily	 	Neutral detergent	<ul style="list-style-type: none"> <li>• Damp sweeping</li> <li>• Manual washing with flat mop</li> </ul>
<b>Periodic cleaning</b>				
<b>Mechanical cleaning</b>	Following patient departure	   or  almond or 	Neutral detergent or alkaline detergent if soiled	<ul style="list-style-type: none"> <li>• Damp sweeping</li> <li>• Mechanical washing at 300-450 rpm (with water recovery)</li> </ul> or <ul style="list-style-type: none"> <li>• Steam cleaning</li> </ul>
<b>Deep cleaning</b>				
<b>Mechanical cleaning</b>	Once every 3 months	   or  almond almond	Alkaline detergent	<ul style="list-style-type: none"> <li>• Damp sweeping</li> <li>• Mechanical washing at 300-450 rpm (with water recovery)</li> </ul>

To offer you the best results in terms of hygiene and appearance, **Gerflor recommends that you use neutral and alkaline detergents with high wetting power** (perfect spreading and cleaning of the entire floor surface).

### Here is a non-exhaustive list of products recommended by the main manufacturers:

**KIEHL:** Profloor\*  
**TANA:** Green care SR15\*, Floor Cleaner S\*, Clean Fresh\*, Difotan\*, Clean Extreme\*\*, Innomat\*\*

**ECOLAB:** Brial Clean S\*  
**ROCHEX:** Polystar\*, Roctonic\*\*  
**BUZIL:** HC 43\*\*  
**DrSCHUTZ:** PU Reiniger\*

**DREITURM:** Multinetzer\*, Goldreif (green)\*, Goldreif (blue)\*, Linorein\*\*, D1 Neu\*\*

\*Neutral / \*\*Alkaline

### CLEANING METHOD FOR:

Mipolam Troplan / Cosmo / Elegance / Accord / Esprit / Symbioz

# HEALTHCARE CLEANING PROTOCOL FOR HIGH AND VERY HIGH INFECTION RISK PREMISES



**Damp sweeping equipment**  
Flexible mop preferably fitted with disposable, antistatic and/or pre-impregnated gauze strips


















**Mechanical cleaning equipment**  
Auto scrubber, rotocleaner or single brush machine



**Manual washing equipment**  
Microfibre disposable mop or gauze



**Steam cleaning equipment**  
Follow the manufacturer's recommendations

	Minimum frequency	Equipment used	Cleaning products	Cleaning methods
<b>First use</b>		  	Alkaline detergent	<ul style="list-style-type: none"> <li>• Damp sweeping</li> <li>• Mechanical washing with blue disk at 300-450 rpm (with water recovery)</li> </ul>
<b>Daily care</b>	Once or twice daily	 	<p><b>In high infection risk area</b> Alternate use of neutral or alkaline detergent and wetting disinfectant detergent</p> <p><b>In very high infection risk area</b> Disinfectant detergent</p>	<ul style="list-style-type: none"> <li>• Damp sweeping</li> <li>• Manual washing with flat mop or mop with reservoir</li> </ul>
	Once or twice daily	   or  or 	Neutral detergent and/or disinfectant detergent	<ul style="list-style-type: none"> <li>• Damp sweeping</li> <li>• Mechanical washing at 300-450 rpm (with water recovery)</li> <li>• Manual disinfectant application</li> </ul> or <ul style="list-style-type: none"> <li>• Steam cleaning</li> </ul>
<b>Periodic cleaning</b>	Once a week	   or  or 	Alkaline detergent and disinfectant detergent	<ul style="list-style-type: none"> <li>• Damp sweeping</li> <li>• Mechanical washing at 300-450 rpm (with water recovery)</li> <li>• Manual disinfectant application</li> </ul> or <ul style="list-style-type: none"> <li>• Steam cleaning</li> </ul>

To offer you the best results in terms of hygiene and appearance, **Gerflor recommends that you use neutral and alkaline detergents with high wetting power** (perfect spreading and cleaning of the entire floor surface).

## Here is a non-exhaustive list of products recommended by the main manufacturers:

**KIEHL:** Profloor\*  
**TANA:** Green care SR15\*, Floor Cleaner S\*, Clean Fresh\*, Difotan\*, Clean Extreme\*\*, Innomat\*\*

\*Neutral / \*\*Alkaline

**ECOLAB:** Brial Clean S\*  
**ROCHEX:** Polystar\*, Roctonic\*\*  
**BUZIL:** HC 43\*\*  
**DrSCHUTZ:** PU Reiniger\*

**DREITURM:** Multinetzter\*, Goldreif (green)\*, Goldreif (blue)\*, Linorein\*\*, D1 Neu\*\*

## CLEANING METHOD FOR:

Mipolam Troplan / Cosmo / Elegance / Accord / Esprit / Symbioz

# HEALTHCARE CLEANING PROTOCOL FOR OPERATING THEATRES



## Damp sweeping equipment

Flexible mop preferably fitted with disposable, antistatic and/or pre-impregnated gauze strips



## Mechanical cleaning equipment

Auto scrubber, rotocleaner or single brush machine

















## Manual washing equipment

Microfibre disposable mop or gauze



## Steam cleaning equipment

Follow the manufacturer's recommendations

	Minimum frequency	Equipment used	Cleaning products	Cleaning methods
<b>First use</b>		  	Alkaline detergent	<ul style="list-style-type: none"> <li>• Damp sweeping</li> <li>• Mechanical washing with blue disk at 300-450 rpm (with water recovery)</li> </ul>
<b>Daily care</b>	When theatre is opened	 or 		<ul style="list-style-type: none"> <li>• Damp sweeping or</li> <li>• Steam dust removal</li> </ul>
	After each procedure	 Sweeping with disposable gauze strips or 	Disinfectant detergent	<p><b>For non-soiling procedures</b></p> <ul style="list-style-type: none"> <li>• Dust removal by damp sweeping at least or using steam</li> </ul> <p><b>In case of soiling</b></p> <ul style="list-style-type: none"> <li>• Damp sweeping followed by manual washing with flat mop or mop with reservoir or</li> <li>• Damp sweeping</li> <li>• Steam cleaning with vacuum suction</li> </ul>
	At end of operating schedule	 or  or  almond	Disinfectant detergent	<ul style="list-style-type: none"> <li>• Damp sweeping</li> <li>• Mechanical washing at 300-450 rpm (with water recovery)</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>• Steam cleaning with vacuum suction</li> </ul>
<b>Periodic cleaning</b>	Once a week	 Sweeping with disposable gauze strips	Alkaline detergent followed by disinfectant detergent	<ul style="list-style-type: none"> <li>• Damp sweeping</li> <li>• Manual washing with flat mop or mop with reservoir</li> </ul>
	Once a week	  or  almond	Alkaline detergent followed by disinfectant detergent	<ul style="list-style-type: none"> <li>• Damp sweeping</li> <li>• Mechanical washing at 300-450 rpm (with water recovery)</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>• Steam cleaning with vacuum suction</li> </ul>

To offer you the best results in terms of hygiene and appearance, **Gerflor recommends that you use neutral and alkaline detergents with high wetting power** (perfect spreading and cleaning of the entire floor surface).

Here is a non-exhaustive list of products recommended by the main manufacturers:

**KIEHL:** Profloor\*

**TANA:** Green care SR15\*, Floor Cleaner S\*, Clean Fresh\*, Difotan\*, Clean Extreme\*\*, Innomat\*\*

\*Neutral / \*\*Alkaline

**ECOLAB:** Brial Clean S\*

**ROCHEX:** Polystar\*, Roctonic\*\*

**BUZIL:** HC 43\*\*

**DrSCHUTZ:** PU Reiniger\*

**DREITURM:** Multinetzer\*,

Goldreif (green)\*, Goldreif

(blue)\*, Linorein\*\*, D1 Neu\*\*

## CLEANING METHOD FOR:

Mipolam Troplan / Cosmo / Elegance / Accord / Esprit / Symbioz

# MAINTENANCE PROTOCOL FOR EVERCARE™ HOMOGENEOUS FLOORS



## Damp sweeping equipment

Flexible mop preferably fitted with disposable, antistatic and/or pre-impregnated gauze strips














## Mechanical cleaning equipment

Auto scrubber, rotocleaner or single brush machine



## Manual washing equipment

Microfibre disposable mop or gauze

	Equipment used	Cleaning products	Cleaning methods
First use			
Mechanical cleaning	  	Alkaline detergent	<ul style="list-style-type: none"> <li>• Damp sweeping</li> <li>• Mechanical washing with blue disk at 300-450 rpm (with water recovery)</li> </ul>
Daily care			
Mechanical cleaning (preferable)	   or  almond	Neutral detergent	<ul style="list-style-type: none"> <li>• Damp sweeping</li> <li>• Mechanical washing at 300-450 rpm (with water recovery)</li> </ul>
Deep cleaning			
Mechanical cleaning	   or  almond	Alkaline detergent	<ul style="list-style-type: none"> <li>• Damp sweeping</li> <li>• Mechanical washing at 300-450 rpm (with water recovery)</li> </ul>

To offer you the best results in terms of hygiene and appearance, **Gerflor recommends that you use neutral and alkaline detergents with high wetting power** (perfect spreading and cleaning of the entire floor surface).

### Here is a non-exhaustive list of products recommended by the main manufacturers:

**KIEHL:** Profloor\*  
**TANA:** Green care SR15\*,  
 Floor Cleaner S\*, Clean Fresh\*,  
 Difotan\*, Clean Extreme\*\*,  
 Innomat\*\*

\*Neutral / \*\*Alkaline

**ECOLAB:** Brial Clean S\*  
**ROCHEX:** Polystar\*, Roctonic\*\*  
**BUZIL:** HC 43\*\*  
**DrSCHUTZ:** PU Reiniger\*

**DREITURM:** Multinetzer\*,  
 Goldreif (green)\*, Goldreif  
 (blue)\*, Linorein\*\*, D1 Neu\*\*

### CLEANING METHOD FOR:

Mipolam Troplan / Cosmo / Elegance / Accord / Esprit / Symbioz